


合格证  
QC PASS

Godox

fotichaestli.ch



Wechat  
Official Account  
神牛微信公众号

深圳市神牛摄影器材有限公司

地址: 深圳市宝安区福海街道塘尾社区耀川工业区厂房2栋 电话: 0755-29609320(8062)

传真: 0755-25723423 邮箱: godox@godox.com

GODOX Photo Equipment Co.,Ltd.

Add.: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District,

Shenzhen 518103, China Tel: +86-755-29609320(8062) Fax: +86-755-25723423

E-mail: godox@godox.com

godox.com

Made in China | 705-WT25R0-02

FCC ID: 2ABYN067  
IC: 20034-25R



WT25R  
WT40R  
WT60R

RGBWW 潜水灯  
RGBWW Dive Light

使用手册  
Instruction Manual

## Safety Instructions and Attentions

First of all, as the most basic principle: This product is a professional lighting set equipment and should be used by professional lighting engineers or under the guidance of professionals. Basic safety attentions must always be followed during use, as follows:

1. Before use, please read and understand these instructions and attentions.
2. Professional lighting is prohibited for children. When children are near, parents or accompanying persons must supervise closely to prevent children from personal injury due to collision with lamps or private use of lamps.
3. This lighting product is not ordinary lighting product and cannot be used for general lighting. Anyone who has suffered eye damage or has sensitive eyes should avoid using this product.
4. When the lamp is on, it must be used with care. Do not touch high-temperature parts, such as LED lamp beads, to avoid burns.
5. When the lamp is on, it is forbidden to look directly at the lamp beads under any circumstances. Strong light should be used under the guidance of professional lighting engineers. Avoid prolonged exposure to strong light under any circumstances. If eye discomfort, please turn off the lamp in time, suspend use, and see a doctor immediately.
6. If the lamp bead is damaged or deformed by heat, stop using this equipment, and contact the manufacturer, service agent or qualified maintenance personnel to replace the lamp bead in time to avoid accidents.
7. This product is only suitable for use in -10°C to +40°C operating environment .
8. Do not use damaged equipment or accessories, and wait for professional maintenance personnel to check and repair to confirm being normal before use.
9. During using, if the casing of this product is broken due to being dropped, squeezed or subjected to strong impact, please do not use it, so as to avoid electric shock injury due to contact with internal electronic components.
10. If an extension cord is required, please use an extension cord with a current rating greater than or equal to that of the equipment. If an extension cord is rated less than the equipment, overheating may result.
11. Some products have long power cords, please place the power cords properly and keep them in a safe place. Avoid contacting the power cord with overheating surfaces, avoid improper placement that could cause pulling damage, or trip on-site personnel. Please use the certified power cord from the original manufacturer. If the product is damaged by using a non-certified power cord, it will not be repaired by our factory.
12. Be sure to unplug equipment from the power outlet before cleaning and repairing. When not in use, do not pull the power cord to unplug the equipment. For normal power-off, please hold both ends of the plug of the equipment with your hands and pull the plug out of power outlet. This equipment needs to be connected to a grounded outlet. Do not disassemble the product without permission. If the product fails, it must be checked and repaired by authorized maintenance personnel.
13. Before storing, make sure that the equipment has cooled down completely. For storage, unplug the power cord from the equipment. The equipment should be placed in the carrying case or in a ventilated dry place.
15. Do not place equipment near flammable and volatile solvents such as alcohol and gasoline.
16. Do not use accessories that are not recommended by our factory to avoid fire, electric shock or personal injury.
17. When cleaning, do not wipe it with a damp cloth, please use a dry cloth or a soft cloth to wipe the dirt of the equipment.
18. Please take off the protective cover before using.
19. This product complies with RoHS, CE and FCC certification, please refer to the relevant national standards for use and operation.

20. The safety instructions are formulated according to the strict testing of the factory, and the design and specifications of the equipment are subject to change without prior notice. For latest product information, please check the GODOX website and view latest electronic instruction.
21. Some products have built-in lithium batteries. Please use specified chargers, and use them within a proper range of the specified voltage and temperature according to the correct operating instructions.
22. Some products are battery powered. Do not use any batteries, power sources or accessories not specified in the instructions for such products. Keep batteries and other accessories out of the reach of children and infants. In the instance that a child or infant swallows a battery or accessory, immediate emergency medical attention is required. If the battery leaks, becomes discolored, deformed, emits smoke, or emits an abnormal odor, remove it immediately. Be careful during removal to avoid burns. Continued use could result in fire, electric shock, or burns. Do not use any deformed or modified batteries. Do not disassemble or modify this product or battery. Do not heat or solder the battery. Keep the battery away from fire or water. Do not incorrectly insert the positive and negative ends of batteries, or mix old and new batteries or batteries of different types together.
24. One-year warranty period, accessories such as consumable batteries, adapters, power cords, etc. are not covered by this warranty.
25. If it is found that the equipment is repaired without authorization, the one-year warranty period will be cancelled and relevant fees will be charged for maintenance. Machine failures caused by non-standard operation are not covered by the warranty.

### keep these instructions!

## Foreword

Thank you for purchasing!

RGBWW Dive Light series has a IP68 waterproof function of up to 40 meters, ultra-high output power, Bluetooth APP smart control, 13 realistic light effects and adjustable brightness from 0% to 100%. This series can be widely used for filling light in diving, underwater photography, underwater recording, underwater light show and etc.

## Main Features


- Smart brightness adjusting ability to enter high light mode under water.
- Waterproof rate IP68, workable up to 40m underwater.
- HSI mode has 36000 colors.
- Color temperature is precisely adjustable from 1800K to 10000K.
- Support Bluetooth APP remote control in abovewater mode.
- Smart battery level indication gives convenience and utility.
- 37 FX modes and freely adjustable brightness.
- RGBW mode allows separated adjustment of red, green, blue and white LED.
- WT25R and WT40R support fast charging through USB Type-C port.

## ▲Warning


- ▲ Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.
- ▲ Keep out of reach of children.
- ▲ Do not use the product in the presence of flammable gases, chemicals and other similar materials. In certain circumstance, please pay attention to the relevant warnings.

- ▲ Built-in lithium battery, do not disassemble, impact, squeeze or put it into fire. If serious bulge occurs, please do not use.
- ▲ Do not leave or store the product if the ambient temperature reads over 40°C.
- ▲ Please use the proper charger and follow the operation instruction.
- ▲ Make sure to seal the charging port with silicone lid and then close the cover before using under water.
- ▲ Please wash it with clean water and put it in a dry and ventilated place after using in the sea.


## Product Structure




1. OLED Panel
2. Power Switch
3. DIM Button
4. + Button
5. MOD/Bluetooth Button



6. FN Button
7. - Button
8. Type-C Charging Port (WT25R/WT40R)
9. DC Charging Port (WT60R)




## Display



1. CCT Icon
2. Bluetooth
3. Underwater Highlight Mode
4. Battery Life
5. Battery Level
6. CCT Value
7. G/M Adjustment
8. DIM Adjust Ratio
9. Over-temperature Alert Icon


15

## HSI Mode Display



1. HSI Icon
2. Bluetooth
3. Battery Life
4. Battery Level
5. HUE
6. HUE Range (0°-360°)
7. DIM Adjust Ratio
8. Saturation
9. Saturation Range (0-100)
10. Underwater Highlight Mode

## RGBW Mode Display



1. RGBW Icon
2. Underwater Highlight Mode
3. Battery Life
4. Battery Level
5. Red Light Icon
6. Green Light Icon
7. Blue Light Icon
8. White Light Icon
9. Red Light Range (0-255)
10. Green Light Range (0-255)
11. Blue Light Range (0-255)
12. White Light Range (0-255)
13. DIM Adjust Ratio


## GEL Mode Display



1. GEL Icon
2. Bluetooth
3. Battery Life
4. Battery Level
5. R-GEL
6. L-GEL
7. DIM Adjust Ratio
8. Underwater Highlight Mode

16


## FX Mode Display



1. FX Icon
2. Bluetooth
3. Battery Level
4. FX No.
5. FX Type
6. FX Level
7. Underwater Highlight Mode
8. DIM Adjust Ratio

## Item List

Model	Item List
WT25R	Light body*1, Type-C charging cable*1, Portable rope*1, 1/4" to 1" ball joint *1, Carry Bag CB67*1
WT40R	Light body*1, Type-C charging cable*1, Portable rope*1, 1/4" to 1" ball joint *1, Carry Bag CB68*1
WT60R	Light body*1, Adapter*1, Power cable*1, Portable rope*1, 1/4" to 1" ball joint *1, Carry Bag CB69*1



Note: Due to continuous updates and upgrades of the products, there may be differences between the actual products and the pictures. Therefore, the pictures are for reference only, products to prevail in kind.

## Separately Sold Accessories



Light Clamp WT-C01


## Operation Instruction

### 1. Power Switch

Long press the power switch for 1 second to power on or off the device. When the light is on in power on status, short press the power switch once in power on status to turn off the light, the DIM value is 0%, short press again to resume the previous DIM value.

### 2. Brightness Adjustment

Short press the DIM button once to make the DIM value blinks. Then short press the + button once can increase the DIM value by 1 unit, long press the + button can increase the DIM value quickly. Short press the - button once can decrease the DIM value by 1 unit, long press the - button can decrease the DIM value quickly. Finally, short press the DIM button once can exit the brightness setting. It will automatically exit the brightness setting when the DIM value stops blinking after 10 seconds of idle use.



### 3. CCT Mode/HSI Mode/RGB Mode/GEL Mode/FX Mode

Short press the MOD/Bluetooth button to switch mode.

#### 3.1 CCT Mode

Short press the FN button in CCT mode to choose CCT adjustment or G/M adjustment.



Short press the + button once can increase the CCT value by 100K or G/M value by 1 unit, long press the + button can increase the CCT value or G/M value quickly. Short press the - button once can decrease the CCT value by 100K or G/M value by 1 unit, long press the - button can decrease the DIM value or G/M value quickly. The CCT value is adjustable from 1800K to 10000K, and G/M value is adjustable from -50 to +50.

#### 3.2 HSI Mode

Short press the FN button in HSI mode to choose HUE adjustment or saturation adjustment.

Short press the + button once can increase the HUE value by 1° or saturation value by 1 unit, long press the + button can increase the HUE value or saturation value quickly. Short press the - button once can decrease the HUE value by 1° or saturation value by 1 unit, long press the - button can decrease the HUE value or saturation value quickly. The HUE value is adjustable from 0° to 360°, and saturation value is adjustable from 0 to 100.



#### 3.3 RGB Mode

Short press the FN button in RGB mode to choose red light adjustment, green light adjustment, blue light adjustment or white light adjustment. Short press the + button once can increase the light value by 1 unit, long press the + button can increase the light value quickly. Short press the - button once can decrease the light value by 1 unit, long press the - button can decrease the light value quickly. The red light/green light/blue light/white light value are all adjustable from 0 to 255.



### 3.4 GEL Mode

Short press the FN button in GEL mode to choose R-GEL or L-GEL.

Short press the + button once in R-GEL mode to enter setting interface, short press the FN button to select among 20 R-GEL modes, then short press again to return to the previous interface.

Short press the + button once in L-GEL mode to enter setting interface, short press the FN button to select among 20 L-GEL modes, then short press again to return to the previous interface.

GEL	Type
R-GEL	128, 153, 156, 165, 723, 724, 220, 342, 720, 910, 990, 16, 17, 38, 47, 65, 92, 93, 4415, 9406
L-GEL	002, 007, 008, 036, 110, 115, 117, 128, 131, 134, 148, 153, 156, 165, 243, 244, 327, 701, 723, 724

### 3.5 FX Mode

Short press the FN button in FX mode to switch light effects.

Short press the FN button twice to return to the previous light effect, Short press the + button or – button can adjust the FX level.



FX Table of WT25R/WT40 R/WT60 R (37 kinds within 13 types)

No.	Icon	Scene	Display I	Display II	Display III
1		RGB cycle	Slow speed	Medium speed	Quick speed
2		Flash	Flash	Press conference	Paparazzi
3		Party	Birth/day party	KTV	Disco
4		Lightning	Discontinuous	Frequent	Sustainable
5		Broken bulb	Discontinuous	Frequent	Sustainable
6		TV	Slow speed	Medium speed	Quick speed
7		Candle	Discontinuous	Frequent	Sustainable
8		Fire	Firewood	Campfire	Fire hazard
9		Firework	Brief	Continuous	Show
10		Police car	Strong flash	Frequent flash	Quick flash
11		Fire truck	Strong flash	Frequent flash	Quick flash
12		Ambulance	Strong flash	Frequent flash	Quick flash
13		SOS			

### 4. Mode Description



Abovewater Mode




Underwater Highlight Mode  
(∞ is displayed on the panel)

### 5. Calibrating Function

The calibrating function is helpful when there are abnormalities in switching between abovewater mode and underwater mode.

Calibrating mode: Long press the MOD button and – button at the same time when the light is dry in abovewater mode to enter calibrating mode.


When the “Calibrating” is displayed on the panel, it means calibration is in process.



When the “√” and “DONE” is displayed on the panel, it means calibration is completed.



When the “x” and “Failed” is displayed on the panel, it means calibration is failed.



### 6. Bluetooth Setting

Long press the MOD/Bluetooth button to enter Bluetooth setting interface. Short press the FN button to choose Bluetooth switch (ON/OFF) or Bluetooth reset. If you choose Bluetooth switch, short press the + button or – button to turn on or off the Bluetooth. If you choose Bluetooth reset, short press the + button or – button to reset the Bluetooth. When “Reset” is displayed on the panel, it means resetting, after which, it will return to Bluetooth setting interface automatically.





Scan the following QR code to download "Godox Light" mobile APP (both Android and IOS systems are available).

For specific operations, please refer to the "Help" manual of the mobile APP, which contains detailed instruction.


Note: the APP can be used directly on the firstly installed device (smartphone or tablet). When changing to other mobile devices, the light shall be reset before normal usage of APP.

## 7. Abnormal Charging Alert

When the  icon appears on the display, there may be battery abnormality, charger abnormality or other abnormalities.



Abnormality alert interface  
in power on status



Abnormality alert interface in  
power off status

## Illuminance Data

### WT25R

CCT	Mode	Illuminance Unit	0.5m	1m	2m
1800K	Underwater	lux	733	198	51.9
		fc	68.1	18.4	4.8
	Abovewater	lux	318	81.9	21.4
		fc	29.6	7.6	2
2800K	Underwater	lux	1310	342	90.1
		fc	121	31.8	8.4
	Abovewater	lux	524	135	35.9
		fc	48.7	12.6	3.3
3200K	Underwater	lux	1370	358	94.1
		fc	127	33.2	8.7
	Abovewater	lux	557	144	38.2
		fc	51.8	13.4	3.6
4300K	Underwater	lux	1690	440	116
		fc	157	40.9	10.7
	Abovewater	lux	692	179	47.4
		fc	64.3	16.6	4.4
5600K	Underwater	lux	2020	527	138
		fc	188	48.9	12.8
	Abovewater	lux	830	214	56.4
		fc	77.1	19.9	5.2
6500K	Underwater	lux	1750	457	120
		fc	163	42.5	11.1
	Abovewater	lux	719	185	48.6
		fc	66.8	17.2	4.5
7500K	Underwater	lux	1700	444	117
		fc	158	41.2	10.8
	Abovewater	lux	690	178	47
		fc	64.1	16.5	4.4
8500K	Underwater	lux	1480	388	102
		fc	138	36	9.5
	Abovewater	lux	606	156	41.4
		fc	56.3	14.5	3.9
10000K	Underwater	lux	1420	370	97.3
		fc	132	34.4	9
	Abovewater	lux	578	149	39.4
		fc	53.7	13.9	3.7

**WT40R**

CCT	Mode	Illuminance Unit	0.5m	1m	2m
1800K	Underwater	lux	2180	582	157
		fc	203	54.1	14.6
	Abovewater	lux	679	179	48,9
		fc	63	16.6	4,6
2800K	Underwater	lux	2710	724	194
		fc	252	67.3	18
	Abovewater	lux	804	214	58,6
		fc	74.7	19.9	5,5
3200K	Underwater	lux	3140	841	224
		fc	292	78.1	20,8
	Abovewater	lux	946	253	68,8
		fc	87,9	23,5	6,4
4300K	Underwater	lux	3360	898	241
		fc	312	83,5	22,4
	Abovewater	lux	1000	267	72,1
		fc	92,9	24,8	6,7
5600K	Underwater	lux	4040	1080	288
		fc	376	100	26,8
	Abovewater	lux	1210	325	87
		fc	113	30,2	8,1
6500K	Underwater	lux	3640	973	259
		fc	338	90,4	24,1
	Abovewater	lux	1080	282	77,1
		fc	100	26,2	7,2
7500K	Underwater	lux	3170	848	226
		fc	295	78,7	21
	Abovewater	lux	952	248	68,2
		fc	88,4	23,1	6,3
8500K	Underwater	lux	3030	809	216
		fc	281	75,2	20,1
	Abovewater	lux	892	233	64
		fc	82,9	21,6	6
10000K	Underwater	lux	3010	805	215
		fc	280	74,8	20
	Abovewater	lux	894	233	64,1
		fc	83	21,6	5,9

**WT60R**

CCT	Mode	Illuminance Unit	0.5m	1m	2m
1800K	Underwater	lux	3150	933	254
		fc	292	86.6	23.6
	Abovewater	lux	750	223	59.9
		fc	69.7	20.7	5.5
2800K	Underwater	lux	3740	1110	300
		fc	348	103	27.9
	Abovewater	lux	918	269	74
		fc	85.3	25	6.8
3200K	Underwater	lux	4270	1260	342
		fc	396	117	31.8
	Abovewater	lux	1020	300	82.5
		fc	95.1	27.9	7.6
4300K	Underwater	lux	5210	1560	418
		fc	484	144	38.9
	Abovewater	lux	1290	382	103
		fc	119	35.5	9.5
5600K	Underwater	lux	5500	1620	442
		fc	511	151	41.1
	Abovewater	lux	1380	406	111
		fc	128	37.7	10.3
6500K	Underwater	lux	4670	1380	374
		fc	434	128	34.7
	Abovewater	lux	1160	340	93.3
		fc	108	31.5	8.6
7500K	Underwater	lux	4220	1240	338
		fc	392	116	31.4
	Abovewater	lux	1060	310	85.1
		fc	98.6	28.8	7.9
8500K	Underwater	lux	4150	1230	332
		fc	385	114	30.9
	Abovewater	lux	1040	305	83.6
		fc	96.9	28.3	7.7
10000K	Underwater	lux	4040	1200	324
		fc	376	111	30.1
	Abovewater	lux	1010	294	80.7
		fc	93.6	27.4	7.4

The above data are average values instead of absolute values.  
 All the above testings are conducted under the condition of 100% brightness.

## Technical Data

Model	WT25R	WT40R	WT60R
<b>Power supply</b>	5V/2.5A, 9V/1.5A, 12V/1A, 15V/0.8A, 20V/0.75A	5V/3A, 9V/3A, 12V/3A, 15V/2.7A, 20V/2A	20V/3.25A
<b>Power underwater</b>	Max.20W	Max.42W	Max.65W
<b>Power abovewater</b>	Max.7W	Max.10W	Max.15W
<b>Charging port</b>	Type-C	Type-C	DC input port
<b>CCT</b>	1800K-10000K		
<b>TLCI</b>	average ≥96		
<b>CRI</b>	average ≥96		
<b>Brightness adjust ment range</b>	0%-100%		
<b>Mode</b>	CCT Mode/HSI Mode /RGBW Mode /GEL Mode /FX Mode		
<b>Water proof rate</b>	IP68 (40 meters underwater)		
<b>Charging time</b>	2h10min at the soonest	2h20min at the soonest	2h at the soonest
<b>Battery life (100% brightness)</b>	≈1h (underwater) ≈3h (abovewater)	≈1.5h (underwater) ≈5h 50min (abovewater)	≈2h (underwater) ≈9h20min (abovewater)
<b>Control Method</b>	Bluetooth APP control (only abovewater)		
<b>Bluetooth control distance</b>	≈25m		
<b>Working environment temperature</b>	-10°C~40°C		
<b>Dimension</b>	57mm*53mm*250mm	57mm*53mm*380mm	57mm*53mm*640mm
<b>Net Weight</b>	0.66kg	1.1kg	1.9kg

Specification and data may subject to changes without notice.

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void

the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

## ▲ Warning

Operating frequency:2402MHz – 2480MHz      WT25R Maximum EIRP Power: 6.57dBm  
WT40R Maximum EIRP Power: 6.90dBm      WT60R Maximum EIRP Power:5.41dBm

### Declaration of Conformity:

GODOX Photo Equipment Co.,Ltd, hereby declares that this equipment are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states.For more information of DoC, Please click this web Link:

<https://www.godox.com/eu-declaration-of-conformity/>

The device complies with RF specifications when the device used at 0mm from your body.

### IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux

deux conditions suivantes :

- ( 1 ) Ce dispositif ne peut causer d'interférences ; et
- ( 2 ) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais

fonctionnement de l'appareil.

Ce matériel est complété par une exposition de rayonnements IC pour un environnement naturel. Ce matériel doit être installé et se faire avec une distance minimale de 20cm entre les radiateurs et les autresYour body shop.



## Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note		

Note: This form shall be sealed by the seller.

### Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

### Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day (purchase date) when the product is bought for the first time. And the purchase date is considered as the date registered on the warranty card when buying the product.

### How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

### Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ① The product or accessory has expired its warranty period; ② Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc; ③ Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ④ The original identifying information of product or accessory is modified, alternated, or removed; ⑤ No valid warranty card; ⑥ Breakage or damage caused by using

illegally authorized, nonstandard or non-public released software; ⑦ Breakage or damage caused by force majeure or accident; ⑧ Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

## Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Circuit Board	12	Customer sends the product to designated site
	Battery	3	Customer sends the product to designated site
	Electrical parts e.g, battery charger, etc.	12	Customer sends the product to designated site
Other Items	Flash tube, power cord, sync cable, modeling lamp, lamp body, lamp cover, locking device, package, etc.	No	Without warranty

Godox After-sale Service Call +86-755-29609320(8062)